


ADDITIONAL SPINDLE SPACERS FOR FATBIKES			
BB Shell Type	RF 30mm Spindle Length	Drive Side Spindle Spacers*	Non-Drive Side Spindle Spacers
BB124/121.5	169.5mm (RF169)	1 x 1.5mm	1 x 11.5mm
	189.5mm (RF189)	1 x 11.5mm	
BB144/141.5	189.5mm (RF189)	1 x 1.5mm	1 x 1.5mm

*Red 2.5mm spindle spacer supplied with BB remains on Drive side spindle on BB121.5/BB141.5 setups in addition to fatbike spacers.

1 MEASURE
Messen
Medir
Mesurer

✗ 89.5/104.5/121.5 /141.5mm
✓ 92/107/124/144mm



2 GREASE
Fett
Engrasar
Graisser

3 HAND PRESS
Von Hand Einpressen
Apretar Con La Mano
Enfoncer à la main



Park Tool™ HHP-2

PLEASE CHECK RACEFACE.COM FOR THE LATEST UPDATES

B30068-B